

# FLORIDA DEPARTMENT OF HEALTH BEST PRACTICES FOR RADON MEASUREMENT

## RADON TESTING HYGIENE PROTOCOL IN TIMES OF COVID-19

### TAKE STEPS TO PROTECT YOURSELF AND OTHERS

- Health and safety first. Stay home if you are sick.
- Contact your client prior to your appointment and confirm whether any occupants to be visited are sick or in quarantine.
- Regularly and thoroughly clean your hands with soap and water for at least 20 seconds.
- Use hand sanitizer with at least 60% alcohol when soap and water is not readily available.
- Cover your mouth and nose when you cough or sneeze.
- Maintain 6-foot distance from others.
- Keep up to date on the latest COVID-19 hot spots and guidance from the Florida Department of Health:  
<https://floridahealthcovid19.gov/>



### CLEAN AND DISINFECT

- Use vinyl/latex-free medical examination gloves, vinyl resealable bags for test equipment, footwear covers/booties, disinfectant wipes and sprays, and multi-surface cleaners/disinfectants.
- Avoid touching your face.
- Wipe the outer surfaces of the deployed devices with disinfectant wipes.
- Before and after measurement, seal “clean” devices into resealable bags after disinfecting. Affix a label with content, date, and signature.
- Place used disinfectant wipes and gloves into a resealable bag.
- Exit building and remove booties and place in a resealable bag.
- Disinfect all resealable bags and place in a bag.
- Disinfect clothing and hands with soap and water or disinfectant wipes and sprays.
- Discard all used resealable bags containing used wipes, gloves and booties into a covered waste container.

**Now is good to test for radon due to increased time indoors.**

Florida Department of Health  
Bureau of Environmental Health  
Radon and Indoor Air Program  
(850) 245-4288  
(800) 543-8279

